Advanced Video powered by Microsoft® Mediaroom™

Quick Remote Guide

Turns TV and box on and off

Rewinds recording or rewinds live TV on DVR

Fast forwards recording

Pauses recording or pauses live TV on DVR

Starts recording or schedules a recording (DVR only)

Plays recording or resumes play after pausing

Stops recorded program

Fast forwards 20 seconds (DVR only allows this on live TV)

Rewinds 7 seconds (DVR only allow this on live TV)

Displays scheduled and stored recordings

Displays various menu options

Takes you back to the previous screen

Use arrows to scroll through menus

Press to select an item

Press to exit screens

Displays information on the current program

Displays channel guide

Changes channels and moves up or down a page on Guide

Changes volume

Takes you back to the previous channel

Mutes volume